






CARBIDE BITS FOR BENCH & ON-THE-CAR LATHES

KWIK-WAY/ SNAP-ON	PART#	QTY	OEM	DESCRIPTION	USE ON MODELS
	802-6	6-pk	109-1092-23, 109-1092-45	<ul style="list-style-type: none"> • Kwik-Way/Snap-On Style Positive Rake Bits for Disc Rotors Tool Holders: 806, 807 	SDL, DL, 850 Disc Lathes, ROTUNDA, Snap-On On-the-Car YA180, YA281 Bench Lathes. Kwik-Way NCL, BDL, CBL108 & Kwik-Lathe. On-the-Car 108-005-04 w/000-0171-91 Screws. 3 cutting edges.
	802-10	10-pk	109-1092-23, 109-1092-45, BTK10A		
	803-10	10-pk	109-1092-32	<ul style="list-style-type: none"> • Kwik-Way Style Formula I Type Positive Rake Bits for Lightning Lathe .032 Radius Tool Holders: 804, 805 	Model 104. 3 cutting edges.
	809-10	10-pk	109-1092-45	<ul style="list-style-type: none"> • Kwik-Way Style Formula I Type Positive Rake Bits for Lightning Lathe .045 Radius Tool Holders: 404, 405 	Model 104. 3 cutting edges.


PRO-CUT	PART#	QTY	OEM	DESCRIPTION	USE ON MODELS
	061-6	6-pk	50-701	<ul style="list-style-type: none"> • Pro-Cut Style Positive Rake Bits Tool Holder: 29005 (not sold by Shark) 	610 Pro-Cut On-the-Car Lathes. 3 cutting edges.
	061-10	10-pk	50-701		
	069-6	6-pk	50-741	<ul style="list-style-type: none"> • Pro-Cut Style Positive Rake Bits for Ford Lathes Tool Holder: 29005 (not sold by Shark) 	610 Pro-Cut On-the-Car Lathes, RJ West PFM 9.2 and FM900, PFM9.2DRO Warthog, 9.2DRO. 3 cutting edges.
	069-10	10-pk	50-742		

PERFECT EQUIPMENT	PART#	QTY	OEM	DESCRIPTION	USE ON MODELS
	407-6	6-pk	D139	<ul style="list-style-type: none"> • Hofmann/RJ West Style Positive Rake Bits for Twin Turn 400/P450 Lathes Tool Holders: 190, 404, 405, 464, 465 (466 Set) 	400/401 True-Cut, 400 & P450 Twin Turn Combination Lathes. 3 cutting edges.
	407-10	10-pk	D139		
	502-6	6-pk	DR L90	<ul style="list-style-type: none"> • Perfect Hofmann Equipment/RJ West Style Negative Rake Bits for Rotor Cutting 	P300 Disc, P350 Combination & P450 Twin Turn Lathes, RJ West 1115 H.D. 6 cutting edges.
	502-10	10-pk	DR L90		
	503-6	6-pk	W136	<ul style="list-style-type: none"> • Perfect Hofmann Equipment Style Negative Bits for Disc/Drum Cutting Tool Holders: 191, 192, 782 (193 Set) 	P300 Disc, P350 Combination & P450 Twin Turn Lathes, 660. 6 cutting edges.
	503-10	10-pk	W136		



Brake Lathe Accessories

CARBIDE BITS FOR BENCH & ON-THE-CAR LATHES

STAR	PART#	QTY	OEM	DESCRIPTION	USE ON MODELS
	808-6	6-pk	CD60	<ul style="list-style-type: none"> Star Style Negative Rake Bits for Drum & Rotor Lathes 	1776 Disc lathes. 6 cutting edges.
	808-10	10-pk	CD60		

SUN ELECTRIC	PART#	QTY	OEM	DESCRIPTION	USE ON MODELS
	061-6	6-pk	PC50701	<ul style="list-style-type: none"> Sun Style Positive Rake Bits for Rotor Lathes 	EEBR105A Deluxe On-the-Car Pro-Cut Rotor Cutting System. 3 cutting edges.
	061-10	10-pk	PC50701		

VBG	PART#	QTY	OEM	DESCRIPTION	USE ON MODELS
	908-6	6-pk	PC50701	<ul style="list-style-type: none"> VBG Style Positive Rake Bits for Rotor Lathes 	600 & 610 On-the-Car Lathes. 3 cutting edges.
	908-10	10-pk	PC50701		



OEM Numeric Crossovers

OEM#	Brand	Shark#	OEM#	Brand	Shark#
000-90488-00	Hofmann/RJ West	407-6	6914-10	Economy Ammco	063-10
080-80000-68	RTI	068-6	6914-10	Super Ammco	062S-10
080-80102-00	RTI	103-6/10	6914-10	Coated Ammco	062C-10
109-1092-23	Kwik-Way/JB	802-10	6914-10	Ammco	068-10
109-1092-32	Kwik-Way/Snap-On/JB	803-10	6914-6	Ammco	062-6
109-1092-45	Kwik-Way/Snap-On/JB	802-10	6914-6	Super Ammco	062S-6
109-1092-45	Kwik-Way/Snap-On/JB	809-10	6914-6	Coated Ammco	062C-6
129005	RELS/Van Norman	902R-10	6914-6	Ammco	068-6
221-538-3	Hofmann/Hunter	703-6/062-6	6918-10	Coated Ammco	104-10
221-538-3	Hunter	103-6	6918-6	Coated Ammco	104-6
221-580-2	Hofmann/Hunter	062-6	722-83-4	Bear	383-6
221-580-2	Hunter	703-10	75-556-2	Hunter	709S
221-617-2 (24)	Hofmann/RJ West/Hunter	062/10/062S-10	7681-10	Ammco	103-10
221-626-3	Hunter	709-6	7681-6	Ammco	103-6
221-639-3	Hunter	065-6	808406	RELS/Van Norman	904-6
221-640-3	Hunter	065-10	866561	RELS/Van Norman	903-6
221-651-2	Hunter	067-6	866562	RELS/Van Norman	902R-6
221-678-3	Hunter	409-6	8711	Performance	065-6 or 10
29005	RELS/Van Norman	505-5 or 10	8712	Performance	067-6 or 10
3330	All Tool	064-6	8731	All Tool	065-6
3331	All Tool	064-10	878051	Accu-Turn	068-6
3334	All Tool	064-6	878052	Accu-Turn	068-10
3336	Performance	064-6	90488	FMC	407-10
3340	Performance	064-10	90817	FMC	062-10
3354	Performance	064-10	91212	RTI	068-10
302167	RELS/Van Norman	902L-6	940610	Ammco	066-10
40435	Accu-Turn/Bosch	060-10	977572	RELS/Van Norman	902R-6
433796	Accu-Turn/Bosch	060-10	A5677-2	Ammco	5677-2
45001	RELS/Van Norman	062-6	BTK10A	Snap-On	802-10
45002	RELS/Van Norman	103-6/10	CD60	Star	808-6
45016	RELS/Van Norman	408-6	D139	Perfect Equipment	407-6
45021	Ranger/RELS/Van Norman	409-6	DRL90	Hofmann/RJ West/PE	502-6
50-701	Pro-Cut/VGB	061-10/908-6	PC50701	Sun Electric	061-6
50-741	Pro-Cut	069-6	V302-07-167	Hunter	702-6
50-742	VGB	908-6	W136-1	Hofmann/RJ West	503-6
50-742	Pro-Cut/VGB	069-10	W139	Hofmann/RJ West	407-6
5677-2	Ammco	A5677-2			
06406-10	Ammco	066-10			
6914-10	Ammco	062-10			

Continued on next page

