

Innovative Superstand 6™

Usage



Before mounting cover, loosen all knobs and tip cradle to downward position as shown.



Mounting Bumper Cover. Lock front casters. Adjust cradle support in a downward position, center the bumper cover on the foam pad. Adjust crosstube to proper length of bumper ends. Tighten knobs. Adjust support arms to proper width of bumper and tighten knobs.



Adjust Inner Support Arms to support center of bumper cover as shown.



The above photo shows a bumper cover properly mounted on the Superstand 6.

For usage videos, visit innovativetools.com

Assembled Innovative Superstand 6™

STOP!

Innovative Tools strongly recommends using Booth Coating Spray to protect against overspray. This will extend product life and provide ease of use.

Note: for plastic bumper covers only. Maximum weight: 25lbs.



For usage videos, visit innovativetools.com



The above photo shows clamping unexposed area of bumper cover.



The above photo shows pinning a bumper cover through existing screw mounting holes.