


PREDATOR

CARBURETOR, GUM AND VARNISH CLEANER



NOTE: PREDATOR™ MAY AFFECT PAINTS AND PLASTICS. CARE SHOULD BE EXERCISED TO AVOID CONTACT WITH EITHER OF THESE MATERIALS. IF ACCIDENTALLY SPRAYED ON PAINT, WASH OFF IMMEDIATELY.

- 1. To clean carburetors: Turn engine off and remove air cleaner. Spray entire inside of carburetor. Next, attach snorkel to valve button so that all parts of the carburetor can be cleaned. Start engine and spray liberally. Lastly, clean the outside of carburetor.
- 2. To clean automatic chokes: Turn engine off and remove air cleaner. Spray both ends of the choke valve while choke is manually being opened and closed by hand.
- 3. To clean PCV systems: With engine off, remove PCV valve (if equipped) and spray liberally.
- 4. To clean heat risers: Engine must be cold. Spray the heater valve shaft at the ends. Allow cleaner to penetrate for a few seconds before moving counter weights up and down.
- 5. To clean carburetor linkage: Simply spray carburetor linkage until clean.

Product Number and Packaging: #1007 - Net wt. 15.75 oz. V.O.C. Aer......12 per case

For complete product specifications, review the product SDS at wellworthproducts.com.

Storage:

Do not store above 120°F (50°C). Do not puncture, incinerate or burn can. Keep away from heat, sparks or open flame.

First Aid Measures:

- EYE CONTACT: Wash eyes with fresh water. If irritation continues, get medical attention.
- SKIN CONTACT: Wash skin with soap and fresh water. If irritation continues, get medical attention.
- INHALATION: Remove to fresh air, give oxygen. Get medical attention.
- INGESTION: Do not induce vomiting-gastric lavage. Get medical attention.

ChemTrec (USA) 800-424-9300