

**TRANSMISSION PARTS LISTING (Continued)**

	PART #	LINE SIZE	DESCRIPTION	REORDER QTY.	PCS. IN TR555
<b>LINE ADAPTERS (Continued)</b>					
	TR950	5/16"	5/16" Rubber To Rubber Connector	2/Pkg.	1
	TR955	5/16"	5/16" Quick Connect To Rubber	2/Pkg.	1
	TR960	3/8"	3/8" & 5/16" Rubber To Rubber Connector	2/Pkg.	1
	TR965	3/8"	3/8" Quick Connect To Rubber	2/Pkg.	1
	TR970	3/8"	3/8" GM 45° Male To Rubber	2/Pkg.	1
	TR975	3/8"	3/8" GM 90° Male To Rubber	2/Pkg.	1
	TR980	3/8"	3/8" GM Straight Male To Rubber	2/Pkg.	2
	TR985	3/8"	3/8" Inverted Flare To Rubber - use with TR605, TR610, TR615 & TR620	2/Pkg.	2
	TR990	3/8"	3/8" GM O-Ring To Rubber - use with TR605, TR610, TR615 & TR620	2/Pkg.	2
<b>UNIVERSAL QUICK CONNECT</b>					
	TR720	3/8"	3/8" Straight Push Quick Connect To Rubber	2/Pkg.	1
<b>TOOLS &amp; ACCESSORIES</b>					
	CL12	1/2"	1/2" Hanger Clamp (includes screw) - use with TR516H 5/16" Rubber Hose	10/Pkg.	10
	CP360	5/16" 3/8"	360° Seal Clamp Pliers	1/Pkg.	1
	TC35	5/16" 3/8"	Tube & Hose Cutter	1/Pkg.	1
	K6806	9/16"	9/16" Seal Clamp - use with TR516H 5/16" Rubber Hose	10/Pkg.	21
	TR775	3/8"	3/8" Trany Connector Clip	5/Pkg.	5